

COLLECTANDRAIN®

Part #871, 5100/5200 Locking Plate Installation Instructions

Start with the Trip Plate in the lower position with the drain valve closed.

- 1. Remove both lower socket head cap screws with their plastic washers and flange bushings using a ¼" hex wrench, while securing the coupling nut with a ½" wrench. Discard the original socket head cap screws.
- Starting on one side, place the plastic washer on one of the new, longer supplied screws from the kit and insert it through the trip plate. Then, slide the flange bushing onto the screw and add a mild thread lock onto the exposed threads.
- 3. Slide the locking plate behind the trip plate and align its mounting holes with the coupling nuts.
- 4. Insert the screw through the locking plate mounting hole and thread the screw into the coupling nut (Do not overtighten the screw, the trip plate needs clearance to slide up and down).
- 5. Repeat step 2-4 for the other side of the locking plate.
- 6. Insert the lock shackle through the lowest accessible lock hole.

