



MODEL 7910 Manual Air Vent

Installation Instructions:

1. Use the flow arrow on the body for reference. Valve must be installed vertically (plumb) and near a high point in each wet pipe system per NFPA 13.
2. Using PTFE tape or other sealant, thread the inlet of the M7910 to a ½" connection.
3. Ensure the valve is open (venting) prior to filling the system.

NOTE: A small amount of water from the valve's outlet is normal for a split second before the float closes and during the bleed step. If the installation location cannot get wet add the optional drain kit or similar provision to the valve's outlet.

4. Fill the system and allow a few minutes for the air to settle once complete.
5. Bleed any residual air which may be trapped behind the float by slightly closing the valve.
6. When all the air has been released, close the valve. **DO NOT LEAVE THE VALVE OPEN DURING NORMAL SYSTEM OPERATION.**

www.agfmfg.com